



## Renaissance Vertical Slider System

Section/Page:	04/03
Issue Date:	01.06
Issue:	0

Glazing & Beading

Vertical Slider

### Installing Glazing Beads

It will be necessary to install the beads with the aid of a plastic mallet.

Starting with the shortest bead, position and tap one end of the bead until it locates and then at intervals of approximately 100mm until the entire bead has located properly.

It will be necessary to bend the last two beads in order to locate the bead retention leg at both ends prior to tapping into position.

### Deglazing

In order to remove the glazing beads, insert a thin spatula or putty knife between the bead and frame in the centre of the longest bead. Levering the spatula will force the bead out. Repeat this operation at approximately 100mm intervals until the bead is free.

