







Type: - Dorpro Flag Hinge

Lateral Adjustment (mm) +/- 4mm

Height Adjustment (mm) +/- 4mm

Finishes: - White, Black, Chrome, Brass, Black Chrome, Brushed Chrome



Adjusting the Dorpro Flag Hinge

- 1. Remove Screw on Edge of Cover plate.
- 2. Remove cover Plate by sliding out towards the lock side to expose the screws.
- 3. Remove the two screws in the lateral position and undo the screws on the height position by two turns.
- 4. Repeat this on the other two hinges.
- 5. Lift the door to the correct position and use packers to keep door in the required position.
- 6. Tighten screws in the height position and insert screws in the lateral position (new holes might have to be drilled).
- 7. Slide cover plate back on and insert screw.
- 8. If lateral movement is required, repeat the above in reverse order.